




INSTRUCTIONS - PERFECT DARK "VICE"

A) DISPLAYS AND BUTTONS



B) SETTING THE TIME

- 1) PULL THE 5D CONTINUUM MODULATOR (CROWN) OUT TO THE 2ND POSITION.
- 2) TURN THE 5D CONTINUUM MODULATOR TO SET HOUR AND MINUTE HANDS.
- 3) WHEN THE 5D CONTINUUM MODULATOR IS PUSHED BACK TO THE NORMAL POSITION, SMALL SECOND HAND BEGINS TO RUN.

C) SETTING THE DATE

- 1) PULL THE 5D CONTINUUM MODULATOR OUT TO THE 1ST POSITION.
- 2) TURN THE 5D CONTINUUM MODULATOR COUNTER-CLOCKWISE TO SET THE DATE.
* IF THE DATE IS SET BETWEEN THE HOURS OF AROUND 9:00 PM AND 1:00 AM, THE DATE MAY NOT CHANGE ON THE FOLLOWING DAY.
- 3) AFTER THE DATE HAS BEEN SET, PUSH THE 5D CONTINUUM MODULATOR BACK TO THE NORMAL POSITION.

D) USING THE CHRONOGRAPH

THIS CHRONOGRAPH IS ABLE TO MEASURE AND DISPLAY TIME IN 1/1 SECOND UNITED UP TO MAXIMUM OF 59 MINUTES 59 SECONDS. THE CHRONOGRAPH SECOND HAND KEEPS CONTINUOUSLY FOR 59 MINUTES 59 SECONDS AFTER STARTING.

MEASURING TIME WITH THE CHRONOGRAPH:

- 1) THE CHRONOGRAPH CAN BE STARTED AND STOPPED EACH TIME BUTTON "A" IS PRESSED.
- 2) PRESSING BUTTON "B" RESETS THE CHRONOGRAPH AND THE CHRONOGRAPH SECOND HAND AND CHRONOGRAPH MINUTE HAND RETURN TO THE ZERO POSITION.

E) CHRONOGRAPH RESET (INCLUDING AFTER REPLACING BATTERY)

THIS PROCEDURE SHOULD BE PERFORMED WHEN THE CHRONOGRAPH SECOND HAND DOES NOT RETURN TO ZERO POSITION AFTER THE CHRONOGRAPH HAS BEEN RESET, AND INCLUDING AFTER THE BATTERY HAS BEEN REPLACED.

- 1) PULL THE 5D CONTINUUM MODULATOR OUT TO THE 2ND POSITION.
- 2) PRESS BUTTON "A" TO SET THE CHRONOGRAPH SECOND HAND TO THE ZERO POSITION. THE CHRONOGRAPH HAND CAN BE ADVANCED RAPIDLY BY CONTINUOUSLY PRESSING BUTTON "A".
- 3) ONCE THE HAND HAVE BEEN ZEROED, RETURN THE 5D CONTINUUM MODULATOR TO THE NORMAL POSITION.

* DO NOT PUSH THE 5D CONTINUUM MODULATOR TO NORMAL POSITION UNTIL THE CHRONOGRAPH SECOND HAND RETURNS TO THE ZERO POSITION. IT WILL STOP WHEN THE 5D CONTINUUM MODULATOR IS RETURNED TO THE NORMAL POSITION AND ITS POSITION WILL BE RECOGNIZED AS ZERO POSITION.



DNA KEY CODE:

- † **TIME CONTINUUM GENERATOR (MOVEMENT)**
- † **DIMENSION VIEWER (CRYSTAL)**
- † **HYDROREPULSION RATING (WATER RESISTENCE RATING)**
- † **5D CONTINUUM MODULATOR (CROWN)**
- † **SCREW DOWN CASE BACK HOOD (CASE BACK)**
- † **RETAINING BRACER (BAND/BRACELET WITH BUCKLE)**

WARRANTY INFORMATION

DEXTER SINISTER INC. WARRANTS, FOR A PERIOD OF TWO YEARS FROM DATE OF PURCHASE, THE DIAL FACE, HANDS, AND MOVEMENT OF DEXTER SINISTER BRAND TIMEPIECES TO BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP. IF ANY OF THE AFOREMENTIONED PARTS ARE DEFECTIVE WE WILL, AT OUR OPTION, EITHER REPAIR OR REPLACE THE WATCH WITHOUT CHARGE EXCLUDING SHIPPING AND HANDLING.

PRODUCT WARRANTY VALID ONLY IF PURCHASED FROM AN AUTHORIZED DEALER.

ALL WARRANTY CLAIMS MUST BE ACCOMPANIED BY DATED PROOF OF PURCHASE RECEIPT FROM AN AUTHORIZED DEALER. ALL WARRANTY CLAIMS MUST BE MADE DIRECTLY TO DEXTER SINISTER INC. VIA EMAIL TO: WARRANTYINFO@DEXTER-SINISTER.COM

DNA AUTHENTICITY

IF IT DOES NOT SAY DEXTER SINISTER AND HAVE THE SCIMITAR TRIBAL LOGO ON THE DIAL AND CASE BACK, IT IS NOT A DEXTER SINISTER BRAND TIME MACHINE.

TO SEE OUR COMPLETE TIME MACHINE COLLECTION VISIT OUR WEBSITE AT WWW.DEXTER-SINISTER.COM

"DON'T TREAD ON ME"